

(!) READ BEFORE USE

ASM

1 AIR SETUP: Minimum 6-8 bar & 400l/min. while spraying. A regulator, that can deliver a minimum of 400 l/min, to control air pressure and a water separator must be installed right before the machine.

3 HEAT: When using aluminium powder, do not set higher than level 4-5. Exceeding this will damage the nozzle.

5 POWER ON: Switch on the back of the machine, then the two switches on the front.

7 TOPCOAT: Always apply a minimum 1 mm layer of topcoat on diamond-cut areas.

9 READ THE FULL MANUAL or watch the video guide on the Knowledge page in SAS.



SCAN THE QR CODE

To register or login to the service and support platform

2 COMPOUND: Do not overfill - fill only up to the line below the eye on the needle. **Shake the bottle thoroughly before use.**

4 FEEDER: Set to 3, maximum 5.

6 PRE-HEAT: Wait 10 minutes before use.

8 SHUTDOWN:

Switch off the front heat, then run maximum air through the nozzle for several minutes until the heater is cool and the gun is clear of compound. Skipping this step **WILL** damage the gun.

Damage from improper shutdown is not covered under warranty.